



1/4

FIG. 1





3/4

FIG. 3




FIG. 4

TRACK NAME	MIDI CH	BANK NO.	WHEN OUTSIDE	WHEN INSIDE	
INDUSTRIAL SE	0	0	ON	MUTE	
DRUM KIT	1	0	ON	MUTE	
MOVE	2	0	ON	MUTE	
FRETLESS BASS	3	0	ON	MUTE	
NYLON GUITAR	4	0	ON	ON	
DRUM KIT VARI	14	0	OFF	ON	
INDUSTRIAL SE VARI	15	1	OFF	ON	
PAD	5	1	ON	MUTE	
VIB	6	1	ON	ON	
PIZZ	7	1	ON	MUTE	
FLUTE	8	1	ON	MUTE	
TOY PIANO	9	1	ON	MUTE	
STRINGS VARI	10	1	OFF	ON	
ACCORDION VARI	11	1	OFF	ON	
FLUTE DELAY	12	1	ON	MUTE	
TOY PIANO VARI	13	1	OFF	ON	